


**de** Montageanleitung  
**en** Mounting instruction  
**fr** Instruction de montage  
**sv** Monteringsinstruktion  
**nl** Montage-aanwijzing  
**it** Istruzione di montaggio  
**fi** Asennus ohjeet  
**es** Instrucción de montaje  
**da** Monteringsvejledning

Temperaturfühler  
 Temperature sensor  
 Sonde de température  
 Temperaturgivare  
 Temperatuuropnehmer  
 Termosonda  
 Lämpötila-anturi  
 Sonda de temperatura  
 Temperaturføler

**QAP...  
 ARG22.1**





**A**



**B** Temp. max. 95 °C !

ARG22.1




**de** Maßbilder  
**en** Dimensions  
**fr** Encombremnts

**sv** Måttuppgifter  
**nl** Maatschets  
**it** Ingombri


**fi** Mittapiirros  
**es** Dimensiones  
**da** Målskitse

**QAP...**



- 1) Wirksame Fühlerlänge  
 Active detector length  
 Longueur de sonde active  
 Effektiv givarlänge  
 Werkzame opnehmerlengte  
 Lunghezza attiva  
 Anturin toimiva pituus  
 Longitud de sonda activa  
 Effektiv følerlængde

**ARG22.1**



Maße in mm  
 Dimensions in mm  
 Dimensions en mm  
 Mått i mm  
 Maten in mm  
 Dimensioni in mm  
 Mitat mm  
 Dimensiones en mm  
 Mål i mm