

Active sensor (4...20 mA) for measuring the temperature in pipe and air applications. Incorporates a stainless steel probe and plenum-rated cable. NEMA 4X / IP65 rated

Technical data sheet

22CT-14H



Type Overview

enclosure.

| | Туре | Output signal active temperature | Cable length | Probe length | Probe di | ameter | |
|----------------|--------------------------------|-------------------------------------|--|---------------------------------------|----------------|---------|--|
| | 22CT-14H | 420 mA | 2 m | 50 mm | 6 m | m | |
| Technical Data | | | | | | | |
| Electrical d | ata Nominal vo | oltage | DC 24 V | | | | |
| | Nominal vo | oltage range | DC 13.5. | 26.4 V | | | |
| | | sumption DC | 0.5 W | | | | |
| | Electrical c | • | Pluggab 2.5 mm² | le spring loaded t | terminal blocl | k max. | |
| | Cable entr | у | Cable gl | Cable gland with strain relief Ø68 mm | | | |
| Functional d | ata Sensor Teo | hnology | Based o | n Pt1000 1/3 DIN | | | |
| | Applicatior | ı | Air | | | | |
| | | | Water | | | | |
| | Multirange | 2 | 8 measu | iring ranges selec | table | | |
| | Current ou | itput | 1x 420 | mA, max. load 50 | | | |
| Measuring d | ta Measured values Temperature | | ature | | | | |
| | Measuring | range temperature | | | | | |
| | | | Active sensor: range selectable Attention: max. measuring temperature is restricted by max. fluid temperature (see S | | table | | |
| | | | | | e is | | |
| | | | | | ee Safety | | |
| | | | data) | | | | |
| | | | Setting | range [°C] | range [°F] | | |
| | | | C 0 | 50 50 | 20 420 | setting | |
| | | | S0 | -5050 | -30130 | | |
| | | | S1 | -10120 | 0250 | | |
| | | | S2 | 050 | 40140 | | |
| | | | S3 | 0250 | 30480 | | |
| | | | S4 | -1535 | 0100 | | |
| | | | S5 | 0100 | 40240 | | |
| | | | S6 S7 | -2080 0160 | 4090 0150 | | |
| | Accuracy te | emperature active | | 0100 21°C [±0.9°F @ 3 | | • | |
| | | tant τ (63%) in air duct | Typical 155 s @ 0 m/s Typical 35 s @ 3 m/s | | | | |
| | | | | | | | |
| | Time const | tant τ (63%) in water pipe | | | contact | | |
| | | | fluid | | | | |
| | | | Typical 7 s with thermowell brass Typical 9 s with thermowell stainless steel | | eel | | |
| Materi | als Cable glan | d | PA6, black | | | | |
| | Mounting | | | RAL7001 | | | |
| | wounting | ματε | rc, grey | | | | |



| _ | | | | |
|-----|------|-----|------|-----|
| Toc | hnic | ata | ch | 201 |
| Tec | | ald | 5116 | 44 |

| Materials | Housing | Cover: PC, orange Bottom: PC, orange Seal: NBR70, black UV resistant |
|-------------|------------------------------|---|
| Safety data | Ambient humidity | Max. 95% RH, non-condensing |
| | Ambient temperature | -3550°C [-30120°F] |
| | Fluid temperature | -50180°C [-60355°F] |
| | Housing surface temperature | Max. 70°C [160°F] |
| | Protection class IEC/EN | III, Protective Extra-Low Voltage (PELV) |
| | Power source UL | Class 2 Supply |
| | EU Conformity | CE Marking |
| | Certification IEC/EN | IEC/EN 60730-1 |
| | Degree of protection IEC/EN | IP65 |
| | Degree of protection NEMA/UL | NEMA 4X |
| | Enclosure | UL Enclosure Type 4X |
| | Quality Standard | ISO 9001 |
| | Mode of operation | Туре 1 |
| | Pollution degree | 3 |
| | Rated impulse voltage supply | 0.8 kV |
| | Construction | Independently mounted control |
| | | |

Safety notes



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorised modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment. Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

| Remarks | |
|------------------------------------|---|
| General remarks concerning sensors | When using lengthy connection wires (depending on the cross section used) the measuring result might be falsified due to a voltage drop at the common GND-wire (caused by the volta |

result might be falsified due to a voltage drop at the common GND-wire (caused by the voltage current and the line resistance). In this case, 2 GND-wires must be wired to the sensor - one for supply voltage and one for the measuring current.

Sensing devices with a transducer should always be operated in the middle of the measuring range to avoid deviations at the measuring end points. The ambient temperature of transducer electronics should be kept constant. The transducers must be operated at a constant supply voltage (± 0.2 V). When switching the supply voltage on/off, onsite power surges must be avoided.



Build-up of Self-Heating by Electrical

Dissipative Power

Technical data sheet

Temperature sensors with electronic components always have a dissipative power which affects the temperature measurement of the ambient air. The dissipation in active temperature sensors shows a linear increase with rising operating voltage. The dissipative power should be taken into account when measuring temperature. In case of a fixed operating voltage (\pm 0.2 V) this is normally done by adding or reducing a constant offset value. As Belimo transducers work with a variable operating voltage, only one operating voltage can be taken into consideration, for reasons of production engineering. Transducers 0...10 V / 4...20 mA have a standard setting at an operating voltage of DC 24 V. That means, that at this voltage, the expected measuring error of the output signal will be the least. For other operating voltages, the offset error will be increased by a changing power loss of the sensor electronics.

If a readjustment directly at the active sensor should be necessary during later operation, this can be done with the following adjustment methods.

- For sensors with NFC or dongle by the corresponding Belimo app
- For sensors with a trimming potentiometer on the sensor board
- For bus sensors via bus interface with a corresponding software variable

Scope of delivery


| Scope of delivery | Description | Туре |
|-------------------|--------------------------|-----------|
| | Mounting plate S housing | A-22D-A09 |
| | Dowel | |
| | Screws | |

Accessories

| Optional accessories | Description | Туре |
|-------------------------------|--|-------------|
| | Connection adapter, M20x1.5, for cable 1x6 mm, Multipack 10 pcs. | A-22G-A01.1 |
| Optional accessories air | Description | Туре |
| | Mounting flange for sensor probe 6 mm, up to max. 120°C [248°F], Plastic | A-22D-A03 |
| | Mounting flange for sensor probe 6 mm, up to max. 260°C, Brass | A-22D-A05 |
| Recommended accessories water | Description | Туре |
| | Thermowell pocket Stainless steel, 50 mm, G1/2", SW27 | A-22P-A06 |
| | Thermowell pocket Stainless steel, 100 mm, G1/2", SW27 | A-22P-A08 |
| | Thermowell pocket Stainless steel, 150 mm, G1/2", SW27 | A-22P-A10 |
| | Thermowell pocket Stainless steel, 200 mm, G1/2", SW27 | A-22P-A12 |
| | Thermowell pocket Stainless steel, 300 mm, G1/2", SW27 | A-22P-A14 |
| | Thermowell pocket Stainless steel, 450 mm, G1/2", SW27 | A-22P-A16 |
| | Thermowell pocket Brass, 50 mm, R1/2", SW22 | A-22P-A18 |
| | Thermowell pocket Brass, 100 mm, R1/2", SW22 | A-22P-A20 |
| | Thermowell pocket Brass, 150 mm, R1/2", SW22 | A-22P-A22 |
| | Thermowell pocket Brass, 200 mm, R1/2", SW22 | A-22P-A24 |
| | Thermowell pocket Brass, 300 mm, R1/2", SW22 | A-22P-A26 |
| | Thermowell pocket Brass, 450 mm, R1/2", SW22 | A-22P-A28 |
| | Syringe with thermal paste | A-22P-A44 |
| | Compression fitting, Stainless steel, G 1/4" (external thread) for 6 mm, with cutting ring | A-22P-A45 |
| | Cold barrier, Plastic, L 50 mm, for thermowell A-22P-A | A-22P-A51 |

Wiring diagram

BELIMO



The adjustment of the measuring ranges is made by changing the bonding jumpers. The output value in the new measuring range is available after 2 seconds.

| Setting | range [°C] | range [°F] | Factory setting |
|---------|------------|------------|-----------------|
| S0 | -5050 | -30130 | |
| S1 | -10120 | 0250 | |
| S2 | 050 | 40140 | |
| S3 | 0250 | 30480 | |
| S4 | -1535 | 0100 | |
| S5 | 0100 | 40240 | |
| S6 | -2080 | 4090 | |
| S7 | 0160 | 0150 | ~ |
| | | | |

Dimensions

