

Duct sensor CO_2 / Temperature

Active sensor (0...10 V) for measuring CO₂, with integrated temperature sensor. Dual channel CO₂ technology with range 0...5000ppm. NEMA 4X / IP65 rated enclosure.

Technical data sheet

22DTC-1105





Type Overview

	Туре	Output signal active CO ₂	Output signal active temperature	
	22DTC-1105	05 V, 010 V	05 V, 010 V	
Fechnical data				
Electrical data	Nominal voltage	AC/DC 24 V		
	Nominal voltage range	AC 1929 V / D	C 1535 V	
	Power consumption AC	2.9 VA		
	Power consumption DC	1.5 W		
	Electrical connection	Pluggable sprin 2.5 mm²	g loaded terminal block max	
	Cable entry	Cable gland wit	h strain relief Ø68 mm	
Functional data	Sensor Technology	CO ₂ : NDIR (non channel	dispersive infrared) dual	
	Application	Air		
	Voltage output	2x 05 V, 010	2x 05 V, 010 V, min. load 10 kΩ	
	Output signal active note	Output 05/10	Output 05/10 V with Jumper adjustable	
Measuring data	Measured values	CO₂ Temperature		
	Measuring range CO ₂	05000 ppm		
	Measuring range temperature	050°C [3212	2°F]	
	Accuracy CO ₂	±(50 ppm + 3%	of measured value)	
	Accuracy temperature active	±0.3°C @ 25°C [±0.54°F @ 77°F]	
	Long-term stability	±50 ppm p.a. ±0.04°C p.a. @ 2	21°C [±0.07°F p.a. @ 70°F]	
	Time constant τ (63%) in air duct		s @ 1 m/s /pical 125 s @ 3 m/s	
Materials	Cable gland	PA6, black		
	Housing	Cover: PC, oran Bottom: PC, ora Seal: NBR70, bla UV resistant	nge	
	Probe material	PA6, black		
Safety data	Ambient humidity	Max. 95% RH, n	on-condensing	
	Fluid humidity	Max. 95% RH, n	on-condensing	
	Ambient temperature	050°C [3012	0°F]	
	Fluid temperature	 050°C [3012	-	



Technical data sheet

Operating condition air flow	min. 0.3 m/s
1 5	max. 12 m/s
Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)
Power source UL	Class 2 Supply
EU Conformity	CE Marking
Certification IEC/EN	IEC/EN 60730-1
Certification UL	cULus acc. to UL60730-1A/-2-9, CAN/CSA E60730-1/-2-9
Degree of protection IEC/EN	IP65
Degree of protection NEMA/UL	NEMA 4X
Enclosure	UL Enclosure Type 4X
Quality Standard	ISO 9001
Mode of operation	Туре 1
Pollution degree	3
Rated impulse voltage supply	0.8 kV
Construction	Independently mounted control

Safety notes



Safety

This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorised modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

Remarks	
General remarks concerning sensors	Sensing devices with a transducer should always be operated in the middle of the measuring range to avoid deviations at the measuring end points. The ambient temperature of transducer electronics should be kept constant. The transducers must be operated at a constant supply voltage (±0.2 V). When switching the supply voltage on/off, onsite power surges must be avoided.
Build-up of self-heating by electrical dissipative power	Temperature sensors with electronic components always have a dissipative power which affects the temperature measurement of the ambient air. The dissipation in active temperature sensors shows a linear increase with rising operating voltage. The dissipative power should be taken into account when measuring temperature. In case of a fixed operating voltage (±0.2 V) this is normally done by adding or reducing a constant offset value. As Belimo transducers work with a variable operating voltage, only one operating voltage can be taken into consideration, for reasons of production engineering. Transducers 010 V / 420 mA have a standard setting at an operating voltage of DC 24 V. That means, that at this voltage, the expected measuring error of the output signal will be the least. For other operating voltages, the offset error will be increased by a changing power loss of the sensor electronics.
	If a readjustment directly at the active sensor should be necessary during later operation, this can be done with the following adjustment methods.
	- For sensors with NFC or dongle by the corresponding Belimo app
	- For sensors with a trimming potentiometer on the sensor board
	- For bus sensors via bus interface with a corresponding software variable
Information self-calibration feature CO ₂	All CO ₂ sensors are subject to drift caused by the aging process of the components, resulting in regular re-calibration or replacement of units. However, the dual channel technology integrates automatic self-calibration technology vs. common used ABC-Logic sensors. Dual channel self-calibration technology is ideally suited for applications operating 24/7 hours such as those in hosiptals or other commerical applications. Manual calibration is not required.




22DTC-1105


Description	Туре	
Manuating flagge fau dust assault 10 Frage up to many 12000 [2400F]		
Mounting flange for duct sensor 19.5 mm, up to max. 120°C [248°F], Plastic	A-22D-A35	
Description	Туре	
Replacement filter, wire mesh, Stainless steel Connection adapter, M20x1.5, for cable 1x6 mm, Multipack 10 pcs. Mounting plate L housing	A-22D-A06 A-22G-A01.1 A-22D-A10	
Description	Туре	
Belimo Duct Sensor Assistant App	Belimo Duct Sensor Assistant App	
Bluetooth dongle for Belimo Duct Sensor Assistant App	A-22G-A05	
* Bluetooth dongle A-22G-A05		
Certified and available in North America, European Union, EFTA States and UK.		
This sensor can be operated and parametrised using the Belimo Duct Sensor Assistant App.		
When using the Belimo Duct Sensor Assistant App, the bluetooth dongle is required to enable communication between the app and the Belimo sensor.		
For the standard operation and parametrisation of the sensor the bluetooth dongle and the Belimo Duct Sensor Assistant App are not needed. The sensor will arrive pre-configured with th factory default settings shown above.		
Requirement:		
- Bluetooth dongle (Belimo Part No: A-22G-A05)		
Procedure:		
 Plug the Bluetooth dongle into the sensor via the Micro-USB connector or by means of the interface PCB 		
- Connect Bluetooth-capable smartphone with Bluetooth dongle		
- Select parametrisation in the Belimo Duct Sensor Assistant App		
	Description Replacement filter, wire mesh, Stainless steel Connection adapter, M20x1.5, for cable 1x6 mm, Multipack 10 pcs. Mounting plate L housing Description Belimo Duct Sensor Assistant App Bluetooth dongle for Belimo Duct Sensor Assistant App * Bluetooth dongle A-22G-A05 Certified and available in North America, European Union, EFTA States at This sensor can be operated and parametrised using the Belimo Duct Secon Assistant App, the bluetooth dongle communication between the app and the Belimo sensor. For the standard operation and parametrisation of the sensor the blueto factory default settings shown above. Requirement: 9 Buletooth dongle (Belimo Part No: A-22G-A05) 10 Buletooth dongle (Belimo Part No: A-22G-A05) 9 Buletooth capable smartphone 9 Buletooth dongle Belimo Duct Sensor via the Micro-USB connector interface PCB 9 Connect Bluetooth capable smartphone with Bluetooth dongle 9 Connect Bluetooth-capable smartphone with Bluetooth dongle 9 Select parametrisation in the Belimo Duct Sensor Assistant App 10 Select parametrisation in the Belimo Duct Sensor Assistant App 10 Select parametrisation in the Belimo Duct Sensor Assistant App 10 Select parametrisation in the Belimo Duct Sensor Assistant App 10 Select parametrisation in the Belimo D	



Wiring diagram



Dimensions



Weight

0.27 kg